Canusa Repair for PE & PU Main Line Coatings

Score around the damaged area with a Stanley knife, removing angular edges.

Use a wire brush to rough the surface and thoroughly clean the area and degrease. Gently heat the area to 60°C and infill the damaged area with a melt stick or mastic filler and then apply the repair patch.

If the damage is superficial, i.e. a cut or scuff that is not through to the steel, the melt stick application is sufficient. If the damage is deeper, apply a Canusa Patch to the area by heating the mastic side and placing it over the filled, damaged area. Continue to apply heat, and roll / pat down the patch until all air bubbles are out and adhesive can be seen around the edges of the patch.